## LIGHTING SYSTEM PRECAUTION

055T5-01

## 1. PRECAUTION OF HEADLIGHT BULB REPLACEMENT

- (a) If the adhered oil is left unremoved from the halogen lamp surface, the lamp service life is shortened as it becomes hot when it is turned on.
- (b) Since the internal pressure of a halogen lamp is high, dropping, hitting or damaging the bulb may cause the glass to scatter. Therefore, handle it with great care.
- (c) When replacing bulbs, do not remove until a new bulb is prepared.
  Because if it is left being removed for a long period of time, the lens may be covered with dirt or moisture.
- (d) For replacement, be sure to use a bulb of the same watt.
- (e) Firmly reinstall the socket after bulb replacement. Otherwise, cloudy lens or invasion by water will be caused.