
DTC	23	PRESSURE SWITCH CIRCUIT
-----	----	-------------------------

CIRCUIT DESCRIPTION

The pressure switch sends the appropriate signals to the A/C amplifier when the A/C refrigerant pressure drops too low or rises too high. When the A/C amplifier receives these signals, it outputs signals via the A/C amplifier to switch OFF the compressor relay and turns the magnetic clutch OFF.


DTC No.	Detection Item	Trouble Area
23	Open in pressure sensor circuit. Abnormal refrigerant pressure. below 196 kPa (2.0 kgf/cm², 28 psi) over 3,140 kPa (32.0 kgf/cm², 455 psi)	Pressure switch Harness or connector between pressure switch and A/C amplifier Refrigerant pipe line A/C amplifier

WIRING DIAGRAM



INSPECTION PROCEDURE

1 INSPECT HEATER CONTROL HOUSING SUB-ASSY(PSW)



- (a) Install the manifold gauge set.
- (b) Turn ignition switch ON.
- (c) Check voltage between terminal PSW of A/C amplifier connector and body ground when refrigerant pressure is changed.
- (d) The voltage changes with refrigerant pressure, as shown in the diagram below.

Voltage:

Low Pressure Cut Side	Reference: High Pressure Cut Side
ON (0V) 196 kPa OFF (12V)	ON (0V) 2,550 kPa ▼ 3,140 kPa OFF (12V)

Α	NG
В	OK (when checking from the PROBLEM SYMPTOM TABLE)
С	OK (Checking from the DTC)

В


PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOM TABLE

C

CHECK AND REPLACE HEATER CONTROL HOUSING SUB-ASSY



2 INSPECT COOLER CONDENSER ASSY(PRESURE SW)



- (a) Turn ignition switch ON.
- (b) Check continuity between terminals 1 and 4 of pressure switch when refrigerant pressure is changed.
- (c) The continuity changes with refrigerant pressure as shown in the diagram below.

Continuity:

Low Pressure Cut Side	Reference : High Pressure Cut Side
ON (continuity)	ON (continuity)
196 kPa ▼ 225 kPa	2,550kPa
OFF (continuity)	OFF (continuity)

NG)

REPLACE COOLER CONDENSER ASSY

OK

3 CHECK HARNESS AND CONNECTOR(BETWEEN PRESURE SW AND HEATER CONTROL HOUSING SUB-ASSY)

NG REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

CHECK AND REPLACE HEATER CONTROL HOUSING SUB-ASSY