PRESSING POWER SWITCH DOES NOT TURN ON SYSTEM

INSPECTION PROCEDURE

1 CHECK CABIN

(a) Check that conditions in the cabin are not likely to cause condensation.

HINT:

This problem occurs when the cabin is humid and the temperature rapidly changes. This condition may produce condensation, resulting in a short circuit.

Standard: Condensation is not likely.

NG DRY CABIN AND RECHECK CONDITIONS

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE (SEE PAGE 05–1914)