
DTC 12 AMBIENT TEMPERATURE SENSOR CIRCUIT

CIRCUIT DESCRIPTION

This sensor detects the temperature outside the cabin and sends the appropriate signals to the A/C amplifier.


DTC No.	Detection item	Trouble Area
12	Open or short in ambient temperature sensor circuit	Ambient temperature sensor Harness or connector between ambient temperature sensor and clock, between clock and A/C amplifier A/C amplifier Clock

WIRING DIAGRAM



INSPECTION PROCEDURE

INSPECT COOLER (AMBIENT TEMP. SENSOR) THERMISTOR



- (a) Remove cooler (ambient temp. sensor) thermistor.
- (b) Measure the resistance according to the value(s) in the table below.

Standard:


Tester connection	Condition	Specified condition
A1-1 - A1-2	10°C (50°F)	3.00 to 3.73 k Ω
A1-1 - A1-2	15°C (59°F)	2.45 to 2.88 k Ω
A1-1 - A1-2	20°F (68°F)	1.95 to 2.30 k Ω
A1-1 - A1-2	25°C (77°F)	1.60 to 1.80 kΩ
A1-1 - A1-2	30°C (86°F)	1.28 to 1.47 kΩ
A1-1 - A1-2	35°C (95°F)	1.00 to 1.22 kΩ
A1-1 - A1-2	40°C (104°F)	0.80 to 1.00 kΩ
A1-1 - A1-2	45°C (113°F)	0.65 to $0.85~\text{k}\Omega$
A1-1 - A1-2	50°C (122°F)	0.50 to 0.70 k Ω
A1-1 - A1-2	55°C (131°F)	0.44 to 0.60 kΩ
A1-1 - A1-2	60°C (140°F)	0.36 to 0.50 kΩ

NOTICE:

Even slightly touching the sensor may change the resistance value.Be sure to hold the connector of the sensor.

HINT:

As the temperature increases, the resistance decreases (see the chart below).



NG

REPLACE COOLER (AMBIENT TEMP. SENSOR) THERMISTOR


OK

2 CHECK HARNESS AND CONNECTOR(COOLER(AMBIENT TEMPERATURE SENSOR) THERMISTOR – CLOCK ASSY)

NG REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

3 INSPECT CLOCK ASSY



- (a) Remove clock assy with connector.
- (b) Turn the ignition switch to the ON position.
- (c) Measure waveform between terminal DATA and body ground of clock assy connector at each temperature.

Standard: Pulse generation

HINT:

As the temperature increases, the voltage decreases.

NG > CHECK AND REPLACE CLOCK ASSY

OK

4 CHECK HARNESS AND CONNECTOR(CLOCK ASSY – HEATER CONTROL HOUSING SUB-ASSY)

NG REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

CHECK AND REPLACE HEATER CONTROL HOUSING SUB-ASSY